

3. select proper screws and place in designated holes. (Aft sling stud screw requires loctite and installed through stud)

